



Orbital Shower
Installation Model: Basic

Quick installation guide

ORBITAL



Basic

Please note: This document does not replace the installation manuals. For installation purposes, please use the respective Orbital Shower installation manuals.

Step. 1

- Prepare shower space



Step. 2

- Mount drain unit and sewage piping



Step. 3

- Mount piping to shower heads, diverter and control dial



Step. 4

- Install incoming water (hot & cold)
- Install power supply



Step. 5

- Cover wall
- Raise floor



Step. 6

- Apply waterproofing membrane



Step. 7

- Tile walls and floor
- Mount core fixtures and brackets



Step. 8


- Mount Orbital Shower Core to brackets
- Install smart sensor unit inside drain unit



Step. 9

- Install shower heads, diverter and control dial
- Connect cables and pipes to the Orbital Shower Core





Installation completed

For comprehensive installation material please visit
www.orbital-systems.com

www.orbital-systems.com



CERTIFIED SPACE TECHNOLOGY